



www.FixMyBlinds.com

*Mini Blind, Wood Blind
& Venetian Blind Restrung
Instructions*

* If you have a string that has not yet broken, use this short cut.

Remove the cap that covers the hole in the bottom rail, and you should see the end of the string tied in a knot. Pull that string towards you, and cut the knot off.

Have the roll of new string nearby. With a cigarette lighter, light the end of the new string until it catches on fire. (*This will not work on 3.2mm, 3.6mm, 4.0mm or 4.8mm Cotton Cord.*) Carefully blow out the flame, and immediately push the old string together onto the melted new string. Gently roll the hot joint together in between your fingertips to securely join the strings together. It might be a little warm, so press gently. Once you are finished, give both ends a little tug to make sure that you have a good connection.

String it through the blind by pulling on the tassel or lift cord, and the string should pull right through. When you have pulled the new cord through, go back to the bottom rail and tie yourself a new knot and replace the cap. Make your final length adjustment after all the strings are replaced.

* If you have a string that is broken, you first must take the blind down and feed the cord through the cord lock and head rail.

Then feed the cord through each slat making sure NOT to put the cord through the ladder but on either side of it. Feed it all the way through the bottom rail and tie a knot big enough so that it will not pull through.

Make your final length adjustment after all the strings are replaced. If the cord starts to fray when you are feeding it through the slats, you may want to light the end of the cord with a small flame to melt it into a solid tip.